

ENGINEERING CHANGE NOTICE

Date:	98.11.19		ECN #:		122
Project No.:	D407-627	Created By:	KE	Checked By:	KE
Project Name:	407 Heli-Utility - Pod	Approved By:	KE	Approved By:	(management if req'd) N/A
Description of Change:					
<p>Revised: D2202 to Rev D Released: D2846 Rev A</p> <p> D2694 to Rev C D2847 Rev A</p> <p> D2764 to Rev D D2848 Rev A</p> <p> D2796 to Rev C D2851 Rev A</p> <p> D2852 Rev A</p> <p> D2853 Rev A</p>					
Notification/Acceptance		Affected ✓	Authorization		
QA		✓			
Production		✓			
Planning		✓			
Marketing		N/A			
Engineering Actions	Yes	No	Responsible	To happen by:	Complete
Update Blue File		✓			
Update Pink File		✓			
Update D-Part Master Binder	✓		KE	98.11.19	KE 98.11.19
Update Grey Project Binder	✓		KE	"	KE 98.11.19
Update DEO Binder		✓			
Update Master Document List	✓		KE	"	KE 98.11.09
Update Drawing Approval Record	✓		"	"	KE 98.11.19
Notify TCA of Change	✓		"	"	KE 98.11.19
Notify FAA of Change		✓			
Notes:					
<p>ECN release</p> <ul style="list-style-type: none"> NOTE: We are still waiting for approval for this package. Keep production units to a minimum until approval received. revised D2694 for new hole pattern, Tool DT8023 may need to be reworked HAAS programming to be created for D2846 support arm and D2847 clevis HAAS base plate for D2846 uses holes per attached sketch HAAS program to be changed for D2764 and D2796 - new wall thickness, slot removed on D2796 HAAS, can use D2764 to make D2796 with additional hole (see D-Part dwg) On IPP D350-602-011/-012 add line to pick D2852 and D2258-160 labels. Install D2258-160 label on pod. Include D2852 label with paperwork (QTY 2 per pod). On IPP D407-627-013 add line to pick D2853, D2852, and D2851-154 labels. Install D2853 and D2851-154 labels on pod. Include D2852 label with paperwork (QTY 2 per pod). On IPP D2694, change D2202-2 Pod Base to read D2202-3 Pod Base On IPP D2202-1, add note to paint grey spackle. Spray clear lacquer after paint has dried. On IPP D2202-3, add note to bond D2693 doublers with 2 part epoxy, and paint grey spackle. Spray clear lacquer after paint has dried. On all IPPs, ensure new revision letters of all updated dwgs are called up. 					